



Screen Up Freestanding Joiner Post

Screen Up / Screen Up Freestanding

- Two-way: joiner or end post
- Available in 1.1m and 2m heights
- Quick and easy to set up - professional looking results
- Long-life powder coated aluminium



VERSATILE: JOINER OR END POST

Whites Screen Up Freestanding Joiner Post is a versatile and decorative addition to the Screen Up range. Build a complete privacy screen that spans longer distances without wall or post support. It anchors securely to the ground for a complete freestanding solution.

Easy as 1-2-3:

1. Position and fix the post
2. Measure and cut timber to size
3. Insert timber, spacers and end caps

The 2-way post is a rectangular profile and can be used as a joiner for straight runs of screening or as an end post. It is available in 2 heights: 1.1m and 2m.

The 1.1m pack comes with step-by-step assembly instructions and contains:

- 2-way Joiner Post (x1)
- 19mm Spacers (x19)
- 10mm Spacers (x4)
- Brace/Cover Strip (x1)
- Lock-in Brackets (x2)
- Post Cap (x1)

As a general guide, the 1.1m post will hold 10 slats @ 90mm width or 12 slats @ 70mm width.

The 2m pack comes with step-by-step assembly instructions and contains:

- 2-way Joiner Post (x1)
- 20mm Spacers (x44)
- 10mm Spacers (x2)

- Brace/Cover Strip (x1)
- Lock-in Brackets (x2)
- Post Cap (x1)

As a general guide, the 2m post will hold 18 slats @ 90mm width or 22 slats @ 70mm width.

[Also available in 3-way configuration. click here for more information.](#)

| Code | Product Description | Type |
|-------|------------------------------|------------------------|
| 16850 | Screen Up Joiner Post - 2m | Suits 19mm width slats |
| 16852 | Screen Up Joiner Post - 1.1m | Suits 19mm width slats |

Handy Hints:

- Select the correct mounting base: if you are fixing the post to an existing surface, use the [Base Plate \(code 16860\)](#); if you are pouring your own concrete base, use the [Anchor Plate \(code 16861\)](#).
- For greater privacy, or the slimline look, use [Screen Up Slimline Spacers \(16870\)](#) that provide a 10mm gap between slats (regular gap 20mm).
- Button head screws (15mm) are recommended for fixing bracing and lock-in brackets.
- Use with [Screen Up Wall Mount](#) for a wall-mount start or end. Both freestanding and wall-mount systems fit together perfectly to create an integrated privacy screen.